Windsor

Installation Instructions

LED Road Light Kirium Pro 1, 2 and 3

230VAC 50Hz

IMPORTANT

- DISCONNECT ELECTRICAL SUPPLY BEFORE INSTALLATION OR SERVICING. • THIS PRODUCT MUST BE EARTHED.
- THIS PRODUCT IS DESIGNED TO OPERATE OUTDOORS. IF REQUIRED TO BE USED INDOORS PLEASE CONSULT DW WINDSOR.
- THIS PRODUCT IS FITTED WITH HIGH IMPACT RESISTANT GLASS AND MAY BE MOUNTED AT HEIGHTS ABOVE OR BELOW 5m.

Product Details

The Kirium Pro range is supplied with entry detached from the luminaire.

	Dimensions (mm)			Max. Weight (kg)*	Windage m ²
	А	В	С		
Kirium Pro 1	610	140	350	8.5	0.048
Kirium Pro 2	720	140	350	9.8	0.052
Kirium Pro 3	1010	167	415	17.1	00.867

*Maximum weight of lantern including post top entry.

	Power Ranges (Watts)			
	Standard	CLO Enabled		
Kirium Pro 1	7-105	6-95		
Kirium Pro 2	22-198	20-177		
Kirium Pro 3	41-394	37-353		

Column Engagement

The information shown below details the length of column engagement for each entry option.

Entry Options	Column Engagement	
76mm Post Top Entry	80mm	
42mm Side Entry	110mm	
60mm Post Top and Side Entry	100mm	




Fig. 2 - Length of column engagement for each entry option

NOTE

NOTE:		
 Luminaire to be positioned so that prolonged staring into the 		
luminaire at distances closer than shown below is not expected.		
o Kirium Pro1 - 3.4m		
o Kirium Pro2 - 4.8m		
o Kirium Pro3 - 6.6m		
 Do not stare at operating light source. 		
Personnel to wear Protective Safety Glasses compliant with EN166 1F/ EN169 - 5		
when commissioning or maintaining this luminaire.		

IP66 IK08 C € ⊕




Fig. 1 - Kirium Pro 2 (Please See Kirium Pro data sheet for all Kirium Pro technical drawings).

Fasteners Supplied

- 2x M10 Screw
- 4x Disc Spring Washer
- 2x M10 Grub Screw
- 2x Locking Nut (for Kirium Pro 2 and 3 only, when using a Side Entry)

Tools Required

Tools not supplied.




Fig. 3 - Kirium Pro 2 (Please See Kirium Pro data sheet for all Kirium Pro technical drawings).

Recommended Torque

	Entry Mounting Torque (Nm)	Column Mounting Torque (Nm)
Kirium Pro 1	16	16
Kirium Pro 2	16	16
Kirium Pro 3	16	16

Kirium® Pro is a registered design.

Due to continuous product development the details within this document are subject to change at any time, please contact us for the most up-to-date information or visit: www.dwwindsor.com

DW Windsor

Pindar Road, Hoddesdon, Hertfordshire, EN11 ODX T: +44 (0) 1992 474600 | E: info@dwwindsor.com dwwindsor.com

Sheet 1 of 4




LED Road Light Kirium Pro 1, 2 and 3

Kirium Pro Installation Steps | Post Top Entry


Step 1

Loosen and remove pre-attached 2x M10 screws and 4x disc spring washers from luminaire with 8mm allen key.




Step 3

Undo quick-release side latches, and leave latches in open position.



Step 5

Loosen cable gland cap within base and feed through cable tail.




NOTE!

LEDs contained within this luminaire shall only be replaced by the manufacturer, their service agent or similar qualified person.




Step 2 (See Step 2A for Side Entry installation instructions) Fit entry to luminaire with supplied fasteners, tightening to 16Nm torque. 4x Disc spring washers must be installed in the correct orientation.



▲ Ensure entry is aligned to desired mounting angle.

Step 4


Pivot lift-off head 45° away from base and remove. Store lift-off head in safe area during base installation.



▲ Undo safety wire before removal of lift-off head. Ensure lift-off head is fully constrained at all times during removal. Kirium Pro 3 Only.

Step 6

Wire cable to electrical disconnect with Pozi or Slotted Screwdriver. Tighten gland cap to 6Nm torque to ensure IP sealing is maintained.



DW Windsor

Pindar Road, Hoddesdon, Hertfordshire, EN11 ODX T: +44 (0) 1992 474600 | E: info@dwwindsor.com dwwindsor.com

Sheet 2 of 4


DW Windsor

LED Road Light Kirium Pro 1, 2 and 3

Kirium Pro Installation Steps | Post Top Entry

Step 7 (See Step 7A for Side Entry installation instructions)

Loosen 2x M10 grub screws on entry with 5mm allen key. Slide entry on to column (See column engagement table). Tighten grubs screws to 16Nm.




Align luminaire with area to be illuminated.


Step 9 (See Step 9A for Side Entry installation instructions) Close luminaire and fasten quick-release side latches.

Step 8

Angle lift-off head 45° and fit to base ensuring both pivot points are fully engaged.




▲ CRITICAL! Attach safety wire to lift-off head before closing luminaire. Kirium Pro 3 Only.



Kirium Pro Installation Steps | Side Entry

Step 2A


Fit entry to luminaire with supplied fasteners, tightening to 16Nm torque. 4x Disc spring washers must be installed in the correct orientation.



▲ Ensure entry is aligned to desired mounting angle.

Step 7A

Loosen 2x M10 grub screws on entry with 5mm allen key. Slide entry on to column (See column engagement table). Tighten grubs screws to 16Nm.



Align luminaire with area to be illuminated.

NOTE!

LEDs contained within this luminaire shall only be replaced by the manufacturer, their service agent or similar qualified person.



DW Windsor

Pindar Road, Hoddesdon, Hertfordshire, EN11 ODX T: +44 (0) 1992 474600 | E: info@dwwindsor.com dwwindsor.com




The Kirium Pro Range

LED Road Light Kirium Pro 1, 2 and 3

Kirium Pro Installation Steps | Side Entry

Step 9A

Close luminaire and fasten quick-release side latches.



Anti-Glare Shield

Anti-Glare Shields can be fitted to the luminaire post-installation, without opening the product.


Fasteners Supplied

Spring Clips and M4 screws are supplied in the following quantities for each anti-glare shield option.


- 2x for Front Shields
- 2x for Back Shields
- 4x for Front & Back Shields (6x for Front & Back Shields on Kirium Pro 3)

Spring Clips

Fit spring clips to luminaire before attaching anti-glare shields. Spring clips are push-fit and non-removeable once fitted.



▲ Ensure Anti-Glare Shield Clips are securely attached to the luminaire.



Tools Required

Tools not supplied.




Fig. 4 - Tools required for Kirium Pro Anti-Glare Shield installation. Not supplied.




Fig. 5 - Kirium Pro front anti-glare shield installation.

